

- 1. SAND** off any existing paint from the area down to the raw composite material, and wipe clean with a clean dry cloth.
- 2. PRIME** the section with one coat of a high grade exterior oil-based/alkyd primer.
- 3. ALLOW** primer to dry according to the manufacturer's instructions - usually 36-48 hours depending on weather conditions and temperature( cold/damp conditions will require longer drying time).
- 4. PAINT** the area with a high quality exterior acrylic house paint.