


# Ultimate Astragal Lite

## Trimming Instructions to Accommodate Varied Door Lengths


**Endura**  
DOOR COMPONENT SYSTEMS  
800.334.2006  
8817 West Market Street  
Colfax, NC 27235

### 1 Remove Astragal Components

Before the astragal body is secured to the passive door, slide the Upper Bolt and Lower Bolt out of the astragal.



### 2 Trim Top of Astragal to Length



Once the astragal body is secured to the passive door, slide the Upper Bolt and Lower Bolt back into the astragal.

Refer to Endura's **Pre-Hanger Installation Instructions for Ultimate Astragal Lite** for complete installation details.