## **ADAptive Sill System**

# Sill Exender Assembly Instruction



#### **Extendable Sills**

#### **Inswing Sills**

- 4-9/16"
- 5"
- 5-5/8"


#### **Outswing Sills**


- 4-9/16"
- 5-5/8"

#### **Extender Sizes**


- 2"
- 3"

#### Step 1: Orient Extender with sill as shown.






#### Step 2: Assemble Extender







b. Slide extender until fully engaged with sill.

# Sill Exender Assembly Instruction




### Step 3: Caulking

If desired, the sill/extender joint can be caulked after assembly.



**A.** Apply a thin bead of silicone or other clear caulking along the joint.



**B.** Wipe away excess caulking.